MATRIX III TURNING RESISTANCE CHART

Matrix III Trucks offer three levels of adjustment:
1. COARSE: Change Shockblock Position (Inside vs. Outside)
2. MEDIUM: Change Shock Color / Hardness (White, Orange, Red)
3. FINE: Compress Shockblock by turning adjustment screw (max 2 turns)

1. COARSE ADJUSTMENT
Choose Shockblock Position (Inside vs. Outside)

INSIDE POSITION	OUTSIDE POSITION
	
Best for: - Riding without bindings - - Low Speed / Sharp Turns -	Best for: - Riding with bindings - - High Speed / Wide Turns -